

## ***Firmware 3.23 for Duplex receivers***

Changes to the 3.22 version:

- Correction of servo outputs setting for R6F and R6G micro receivers.
- The function of microprocessor resets counter added.

### **Resets counter**

This function is available in RxDiag JETIBOX .

Using UP and DOWN buttons on the JETIBOX it is possible to choose between different reset types. High number of individual resets that does not match the number of switching on may highlight the problem with installation, defective connectors, interference on the wires, interference from the ignition etc. It is possible to clear these counters by simultaneous holding LEFT and RIGHT buttons.

ResetA – overall number of resets

ResetB – number of detected undervoltage events

ResetC – number of resets from other reasons than power