

Jeti DC/DS-16 Update Version 2.22 (December 2013)



Tip: ALWAYS backup your models and settings before performing any update. After each update you should verify the settings and throws of a model before your first flight. Make sure that all of the controls are correctly calibrated.

Attention: In case you use a reversed servo throw for the throttle channel, please make sure that the digital throttle idle trim works correctly. In case it doesn't, please go to: *Fine Tuning* → *Digital trim* and set the trim mode to throttle low as it should be by default.



The version 2.20 modifies the evaluation algorithm of the antenna signal strength (RSSI), while still keeping the original numerical range from 0 to 9. The displayed values, however, decrease with distance more linearly.

New features:

1. New language: **Italian**.
2. The menu item for **gyro settings** is also available to the airplane models. When setting-up the model it is possible to activate up to three independent functions for adjusting control gain of a stabilization system. You need to enable the gyro in *Basic Properties* and then go through Function & Servo assignments. In *Functions Assignment* assign any control to this function and in *Servo Assignment* select any output channel of the transmitter. Individual gyro setting itself is located in the menu item *Fine Tuning* → *Gyro settings*.



3. In the menu item *Fine Tuning* → *Flight modes* it is possible to assign a WAV file to each flight mode, which is played in the moment of activating selected mode.
4. In the menu item *Fine Tuning* → *Flight Modes* → *Detail of the flight mode (F4)* it is possible to assign an arbitrary switch to the flight mode voice announcement. After switching on, the actual flight mode will be announced, respectively the WAV file will be played back.



Modifications:


1. Maximum available sound volume increased.
2. New supported receivers in *Device Explorer*: R5L EU, R3.
3. Fixed an issue of lost pre-flight positions and switching levels of the proportional controls when setting a new model.
4. Fixed "Release Button" message during startup.
5. Automatic selection of servo side during process of servo calibration (*Model* → *Servo Setup*, select "Max positive" and move the appropriate stick from left to right and vice versa).
6. Improved function of Rx low voltage alarm/reset of the receiver. In case of the receiver reset (eg. even when switching on), there occurs only the alarm without indicating the voltage value.
7. *Device Explorer*: 4th output pin of receiver R4 (German) can be properly configured as in other language versions.
8. Fixed Czech and French voice number announcements (e.g. 65 000 for the Czech and 72, 96 etc. for the French).
9. Added links to Servo Monitor to Ailevator menu, V-Tail, Delta wing.
10. Analyser of the telemetry data (*Application* → *Data Analyzer*) can now handle more than 32 telemetry values from the log-file record.
11. Improved acoustic signalization of classic MVario (non-EX).
12. Audio is paused whenever a new log is being created or a screenshot is being generated.
13. Ailevator mix is in new models set by default to 100% for elevator and 0% for ailerons.
14. Several sensor variables are aggregated into a single line in the log file. This helps to shrink the log file into a smaller size.
15. Fixed "Teacher mode" when the primary receiver disconnected, so the PPM output is still usable, eg for connecting the external module.
16. The clock panel is able to display receiver voltage, model time and antenna signal strength (*Timers/Sensors* → *Main Screen*).
17. Fixed CRC of EX data stream from DC-16 inner connector, eg for connecting the RCDroidBox.

Jeti DC/DS-16 Update Version 2.20 (October 2013)

New features:



1. Improved software selection for heli pilots: **Swash Ring**, enhanced **gyro settings** and **heli model wizard** for the initial configuration of a model (see Notes).
2. **Servo balancer** for use with multi-servo wing surfaces (see Notes).
3. A simple **password protection** against unwanted modifications to a model configuration (see Notes).
4. The Device Explorer is able to generate on-demand commands to EX Bus compatible devices (see Notes).
5. Added support for German localization of current EX Bus devices. The chosen language depends on the transmitter's system language. Note: The devices of Czech and French localization are always shown in the original language.
6. You can view the telemetry value from any sensor instead of the digital clock in the upper display panel. Use *Timers/Sensors* → *Main Screen* to set an appropriate sensor parameter. (see Notes, Servo balancer section).
7. In *System* → *Configuration* it is now possible to check the signal strength immediately after the model is turned on and connected to the transmitter. If you set *Yes* for this option, a warning message is generated for antenna signal levels less than 8. To make this function work correctly, you should be located a distance of up to several meters from the model at the moment of switching it on. If the message is still present, please perform a range test and check the installation of the on-board electronic equipment.
8. The *System* → *Configuration* now contains the possibility to configure the internal connector labeled as **PPM Output**. (please refer to the DC/DS-16 user manual, chapter 3.7 *PPM Output Connector*):
 - Off – the connector output (pin No. 4) will not generate any kind of signal.
 - PPM Positive – the connector output (pin No. 4) will generate standard eight-channel PPM signal with positive pulses.
 - PPM Negative – the connector output (pin No. 4) will generate inverted eight-channel PPM signal with negative pulses (0V level).

- EX Data Stream – the connector output (pin No. 4) will generate a digital data stream containing EX telemetry. The format of transmitted sensor/receiver data is described in the document [JETI Telemetry Communication Protocol](#). The communication is unidirectional and cannot be used to configure the transmitter or any linked device. If you connect the RCDroidBox device to the transmitter, you will need to set this option.
2. New, added function for the internal connector: **PPM input** (please refer to the DC/DS-16 user manual, chapter 3.7 *PPM Output Connector*). The transmitter can handle up to 8 channels of the PPM input signal. The signal should be present on the pin No. 1 (the DC/DS-16 user manual calls this pin as reserved). To prevent any damage, you need to use the 3V logic level and protective elements on the input. Within the application you can assign any of the PPM channels to any function of the transmitter – use a standard control input selection dialogue. The PPM input is not linked with the trainer system in any way and works separately. Possible use in cooperation with head-tracking systems etc.



1. Another new function has been added: Now it is possible to store service information of the transmitter, alarms, and position of up to 4 controls (as markers) on your SD card. Then the data is a part of logged flight telemetry. In the menu *Timers/sensors* → *Sensors/Logging setup* go to the item *Transmitter status info* and push the 3D button. In the menu it is possible to select whether the text information about the alarms and other general data about the transmitter state will be stored (by default it is disabled). Note that some PC programs for the evaluation of telemetry data can recognize the text information as an error in the data file. To view the information, you should use the built-in *Data analysis* application or update the PC program.


In this menu you can also select up to four controls whose position will be recorded in a file on the SD card. It is possible to select between recording of proportional or two-state values (0% – 100%). The control positions are recorded with a fixed period of 0.2s. The data is a part of the standard telemetry record and can be displayed as the other parameters.



This application can easily be used as a marker to highlight interesting situations during the flight.

Modifications:

1. Functionality of digital trim in *ThroLow* and *ThroHigh* modes with reversed servo channel has been fixed.
2. When selecting audio files, those items that begin with a dot in the name are not displayed. In some systems, they are hidden, respectively temporary files.
3. Security question to prevent accidental switching from (S)eparate mode of function into (G)lobal was added to all dialogues in the section *Fine Tuning*.
4. After pushing Menu button within any dialogue, the main screen always appears.
5. The support of **RC Switch** has been improved. If you use an RC Switch, it is necessary to update your transmitter. The support for **Central Box 200** and **R3 EX** has been added.
6. The algorithm for processing the input of the student transmitter in the teacher-student mode has been improved.
7. Playing files in the *Audio Player* application is not influenced by *Sounds on events*. Played audio files will now blend.
8. Voice telemetry output is now not interrupted at the moment when an audible indication of timers should occur. Instead of that, the event of the timer is now indicated by one beep.
9. **Low voltage alarm of the receiver** is now accepted based on the setup of the receiver. This alarm is also indicated when the receiver is reset (such as disconnecting and reconnecting the power supply).
10. In Double Path mode it is possible to display the voltage of both connected receivers on the telemetry panel on the main screen. The minimum and maximum voltage of the receiver/receivers is also displayed here.
11. Display of the signal strength for both receivers in the Double Path mode on the telemetry panel on the main screen. To show all four values of antenna signal strength go to *Timers/Sensors* → *Displayed Telemetry*, add a new item *Antenna* and set the “Double” option to *Yes*.
12. Displaying of the signal strength has been modified – the percentage success of bidirectional communication, which is in the range of 0-100% has been added. Status of signal levels in the upper left corner of the screen is now indicated according to the success of transmission, expressed as a percent.
13. The evaluation of signal levels for conversion to the 0-9 scale has been modified. Now the signal strength is more linear with the distance.
14. Saving of the voltage of the receiver / receivers, signal strength and the success rate of transmission is now possible. This data is saved on the SD card along with the EX telemetry and the voltage of the receiver.
15. In the Data analyzer application it is possible to delete telemetry files when browsing through the directories.
16. In the Data analyzer application a text description of the alarm at a given time is displayed. The recording of text information to the SD card must be enabled via *Timers/Sensors* → *Sensors/Logging Setup*.



Notes:

Improved options for setting up model helicopters

Cyclic limitation of rotor head control (Swash Ring)

Tx	Default	12:22:33	57%
Swash Mix			
Roll	50%		
Elevator	50%		
Pitch	50%		
Swash Ring	<input checked="" type="checkbox"/>		
Value	100%		
Back			Next

In the menu *Model* → *Swash Mix* it is possible to activate the function of the cyclic limitation for a helicopter rotor head. Activating this function causes the restriction of servo travel in the combined full deflection of the roll and pitch controls so that the total size of the deflection is always within the inner area of the displayed circle. Outside the circle there is a kind of a dead zone of the flight controls.

Editing an item *Value* affects the diameter of the displayed circle, ie. size of the maximum allowed deflection. The setting is global for the whole model.

Advanced options for gyro settings

Tx	Default	12:22:00	57%
Basic Properties			
Angle	120°	Rotation	0°
Lever lengths (Servo 1-3):			
100%	100%	100%	
Governor	No		
Use gyro 2	No		
Use gyro 3	No		
Back			Next

Now it is possible to make up to three independent functions for controlling gyro gain. By default, gyro No. 1 is always active. The others are activated in the *Model* → *Basic Properties* menu together with the Governor function.

Note: If you activate the additional function of the gyro in the active model, after leaving the *Basic Properties* menu it is necessary to carry out the control assignment (*Functions Assignment*) and then select the appropriate output channel (*Servo Assignment*). Setting the gyro gain itself is carried out in

the *Fine Tuning* → *Gyro Setting* menu.

Tx	Default	12:22:36	57%
Gyro settings			
Position 1	Tuning	[Gyro sens.]	
-50% (-50)	...	0%	S
Position 3	Tuning	[Gyro sens2]	
50% (50)	...	0%	G
Position 3	Tuning	[Gyro sens3]	
50% (50)	...	0%	G
Ok			


In the Gyro settings menu it is possible to edit up to three main values for each gyro function in all flight modes separately according to the position of the main control/switch.

Moving the switch to the selected position causes an automatic update of the depicted values in the appropriate line. Set the main value of the gyro gain to the needed value (highlighted in the picture), eventually also assign an appropriate control for fine tuning – here it is necessary to set also the percentage range of the control influence. For each position of the main control it

is possible to individually assign an independent control for fine tuning of the gyro gain. The resulting applied gain value is displayed in parentheses (-50% in this case).

Note: Negative values of gyro gain indicate the gain in “Normal” mode, positive values indicate the gain in the „Heading-lock“ mode.

Advanced options of Governor settings



Like in Gyro gain settings, it is also possible to select up to three main values for governor RPM control in the *Governor settings* menu (0% means zero RPM, 100% means full throttle). It is also possible to assign a specific control to each governor position (switch, stick or knob), which can precisely tune required RPM – in this case it is necessary also to specify the range of the influence of the tuning control to the RPM. The resulting applied value of the Governor function is displayed in the parentheses. The setting can be global for all flight modes or separate for each mode.

Note: The Governor Setting screen has been promoted to an independent item in the *Fine tuning* menu and is no longer a part of the common *Gyro/Governor* menu.


Model Setup Wizard




(Main Menu → Heli Wizard)

This menu simplifies all the basic steps in setting up a model helicopter and it automatically appears after you create a new model helicopter. Thus, it is possible to go relatively quickly through all possible steps, resulting in a fully configured flying model. We recommend proceeding from the first item from the top down step by step. Pushing the **F(3)** button makes it possible to quickly enter the menu for pairing the transmitter with the receiver.

Servo balancer (Model → Servo Setup)



Servo balancer after highlighting by scrolling down through the menu (below servo reverse parameter).




Editing control points of the servo balancer.


The function of the servo balancer is designed for large models that have control surfaces driven by mechanically linked servos. Since each servo can be preset from the factory in a different way and mounting servos into the model is not always accurate, it is now possible to set servo travel algorithmically to ensure minimum mechanical stress during the movement of the controls.

Thus it is possible to assign a separate curve to each output channel, which is applied as the last operation before sending the deflections to the model. Because it is applied last, the curve is ultimately applied to trims, mixes, dual rates, etc., so that servos of the same control surface always move together equally. The Servo balancer can alter the curve of the servo by a maximum of $\pm 10\%$ with a resolution of 0,1%.

After you highlight the graph of the servo balancer, push the 3D button. This enables editing of the servo curve. Now, always one control point is highlighted according to current servo deflection. If the current servo position is -30%, the nearest highlighted control point is located in -25%. It is then possible to move the point upwards or downwards by turning the 3D button to the right, or respectively to the left. In "Auto" mode (the F(2) button is highlighted) simultaneous shifting of neighboring control points occurs, so that the resulting curve is precisely smoothed. Then you can select another control point by moving the servo control and alter this point until the mutual mechanical stress of servos during the movement is minimal.



After pushing the F(1) button when the servo balancer is highlighted, the speed dial is displayed. Here is where you can select one telemetry parameter, which will appear at location of the digital clock on the top bar of the screen. This way you can select eg. displaying the instant current draw from the batteries, which is very helpful when balancing different servo travels.



Note: Setting the display of the telemetry data on the top menu bar of the screen is saved as a part of the model configuration and it is displayed again when the transmitter is switched on. Alternatively, it is possible to adjust the displayed data in the *Timers/Sensors* → *Main Screen* menu. It is possible to select any simple numerical value, but not GPS coordinates or transmitter status.

The **F(2) “Auto”** button enables switching between automatic and manual selection of control points in the servo balancer edit mode. When selecting control points manually, push the **3D** button to move to the next point; pushing the **ESC** button activates the previous check point. When editing in the manual mode, you move (as opposed to the automatic mode) only one control point, the others remain unchanged.


If the **F (3) “Clear”** button is pushed for a short time, it quickly clears a control point (which must be highlighted). If the **F (3) “Clear”** button is pushed and held for longer time, the whole curve is cleared to a default state.

Tx	Default	12:22:23	57%
R9-EX Outputs			
<< Back			
Output pin	Servo No.		Group
OutPin 1	Engine 1 (1)	⬇	A ⬇
OutPin 2	Aileron 1 (2)	⬇	B ⬇
OutPin 3	Aileron 2 (3)	⬇	B ⬇
OutPin 4	Flap 1 (4)	⬇	C ⬇
OutPin 5	Flap 2 (5)	⬇	C ⬇
Back	✕	↺	⬇ CMD Ok


Advice: If you use several mechanically linked servos to control a single wing surface in the model as shown in this example, we recommend setting all the servos belonging to this surface into one output group (*Group A-C*). In the picture this is done via the *Device Explorer* application. In this way the servos will receive control pulses at the same time and their movement will thus be synchronous.

Advice: To optimize the servo travels via servo balancer, we recommend that you use an ampermeter (or eg. the current measurement from the MUI sensor displayed in the telemetry window) and always try to make sure that the current running through servos as low as possible.

Password protection against accidental configuration changes




If you lend the transmitter to another person and you want to ensure that no changes in the model configuration that could influence the function of the transmitter or the model can be done, you can take advantage of the **Model Lock** function. In the main menu, push the **F(3)** button to display the dialog for entering the one-time password.



Here, enter the two-digit code using the **F(1)** "1/2/3", **F(2)** "4/5/6" and **F(3)** "7/8/9". This code appears on the display and will later be used to unlock the transmitter.


Pushing **F(4) Clear** enables you to delete the specified number and you can start up again.

Remember the code and push **F(5) OK**. Now confirm the safety prompt "Apply changes?".



From now on the transmitter will be locked against:

- changes in configuration,
- selection of the model,
- creating a new model,
- calibration of controls,
- logging telemetry,
- USB connection,
- switching off.



All the work with the SD card therefore takes place in read-only mode.

Unlocking the model is possible via the **F(4)** button in the Main Menu. Now you need to enter the same code as when locking the model. Confirm with **OK** button.

Now you are asked whether you want to save the changes to the configuration of the model or not.


Pushing **F(1) NO** button makes all the changes discarded and all the data from the SD card will be reloaded.

Notice: This function cannot in any case be used to increase safety, eg. against the theft of the transmitter. The transmitter is locked against configuration changes from the moment you enter the code until the transmitter is subsequently switched-off or the code is re-entered. As soon as the transmitter is switched off, (eg. pushing the combination of **POWER+ESC** or removing the power supply) the transmitter is automatically unlocked.

Support of remote commands for EX Bus devices



The list of active commands.




Sa switch is assigned to reset minimums, maximums, and the measured capacity. For the reset command only the *Control* mode is available (the position of the control/switch is taken as an input), other devices may accept a proportional value specified as a constant or as the channel number on the transmitter.

The DC-16 and DS-16 transmitters support up to 16 universal commands for wirelessly connected devices supporting EX Bus. To view the list of active commands, press the **F(4) CMD** button when in the *Model* → *Device Explorer* menu. However, the command must be detected before it can be activated. As an example of the use of wireless commands, the Central Box can be used and its command that resets the minimum, maximum values and battery capacity (*Clear MIN / MAX values*).



Scroll to view minimums and maximums.



Pushing the 3D button enables you to add the command into the list of active commands and it is possible to assign a transmitter control to it.

On the main screen of the Central Box settings scroll down to display the maximum telemetry values (*Telemetry Min/Max*). Here you will find a choice to assign a switch to the command for deleting measured minimums and maximums (*Clear Min/Max switch*). Pushing the 3D button on this item you are moved to the list of active commands where this command is already listed and is inversely highlighted with a cursor.

Pushing the 3D button moves you to the choice to assign the control/switch that will further on take care of the command for resetting. Here we have chosen the *Sa* switch.

Further operation of the command will look like this:

- Moving the *Sa* switch into the ON position makes the transmitter detect that it should send the command for resetting telemetry minimums and maximums to the model. However, before the command is applied, it is necessary to confirm the choice by the pilot to avoid unwanted resetting of the data.
- The transmitter displays a dialog asking if you want to execute the command for resetting the telemetry. If you press **NO** or you do not manage to respond in time, the dialog closes and the command is not executed.
- Conversely, if you press **YES**, the command is sent to the model where it is processed by the Central Box which resets its telemetry. The result of this command can be displayed on the main screen of the transmitter in the telemetry window – the item Capacity of the Central Box will now be set to zero.